

KSS Water Quality Guidelines for Cleaning and Diafiltration

For All Polymeric Membrane and Ion Exchange/Adsorbent Resin Applications

Parameter	MF/UF	NF/RO & IE/Ads. Resin
Turbidity	< 1.0 NTU	< 1.0 NTU
Suspended Solids (see Note 1)	< 5 mg/l	< 1 mg/l
Calcium (Ca)	< 10 mg/l	< 5 mg/l
Total Hardness (as CaCO ₃)	< 60 mg/l	< 30 mg/l
Iron (Fe)	< 0.05 mg/l	< 0.05 mg/l
Zinc (Zn)	< 0.3 mg/l	< 0.05 mg/l
Copper (Cu)	< 0.1 mg/l	< 0.05 mg/l
Manganese (Mn)	< 0.05 mg/l	< 0.02 mg/l
Aluminum (Al)	< 0.05 mg/l	< 0.05 mg/l
Silica, Reactive (as SiO ₂)	< 10 mg/l	< 10 mg/l
Silica, Colloidal (as SiO ₂)	< 1 mg/l	< 0.1 mg/l
Silicone	0 mg/l	0 mg/l
Total Bacteria Count (TBC)	< 1000 per ml	< 1000 per ml
E-Coli Count	0 per 100 ml	0 per 100 ml
Chlorine (as NaOCl)	< 1 mg/l	0 mg/l
D-Limonene (citrus applications only)	< 5 mg/l	0 mg/l
Fats, Oils and Grease	0 mg/l	0 mg/l
Total Organic Carbon (TOC)	< 1 mg/l	< 1 mg/l
pH (standard units)	6.5 – 7.5	6.5 – 7.5

TABLE NOTES

- ¹ The water supply must be free from particulate matter such as rust, scale, flakes, sandy and granular material, slurries, scum, algae and any chemical constituents that could foul or damage the membranes.
- ² The water pH may need to be adjusted with acid or alkali depending on application and local conditions.
- ³ KSS membranes are available in many configurations and materials that may be affected differently by various water constituents. Softened water or evaporator condensate is generally acceptable for cleaning and flushing of polymeric membranes. Please consult with the KSS Process Group for the particular membrane in question.

The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale and Performance Warranty documentation for additional information.

Koch Separation Solutions, Inc. 850 Main Street, Wilmington, MA 01887
Main: +1-978-694-7000 • Fax: +1-978-657-5208 • Toll Free: +1-888-677-5624

For complete contact information and listing of our global locations, visit www.kochseparation.com

©2020 Koch Separation Solutions, Inc. All rights reserved worldwide. For related trademark information, visit <https://www.kochseparation.com/legal>.